

Parts List

UMAREX HK MP5A2 GBBR

01	Cocking Tube Cap
02	Cocking Tube Screw
03	Front Sight Set
04	3-Lungs Front Barrel
05	Barrel
06	Hop-Up Cap Spring
07	Hop-Up Cap
08	208MM Inner Barrel
09	Hop-Up Set
10	Barrel Screw
11	Receiver Group
12	BB Loading Chamber
13	Rear Sight Assembly
14	Cocking Tube & Lever
15	Bolt Head
16	Enhanced Loading Muzzle
17	Gas Control Valve Spring
18	Gas Control Valve
19	Piston
20	O-Ring 11x2
21	Piston Spring
22	Loading Muzzle Holder
23	Cylinder
24	Bolt Carrier
25	Bolt Head Locking Pin Set
26	Recoil Spring & Guide Rod
27	Buffer
28	Back Plate
29	Buttstock
30	Stock Locking Pin
31	Forearm / Trigger Group Locking Pin
32	Forearm
33	Safety Selector (Right)
34	Safety Selector (Left)
35	Trigger Mechanism Set

36	Navy Trigger Housing
37	Magazine Housing
38	Magazine Follower
39	Magazine Airtight Rubber
40	Magazine Ceiling Plate
41	Magazine Valve
42	Magazine Follower Spring
43	Magazine Inner Tank Support
44	Magazine Inner Tank
45	Pin $\varnothing 2 \times 18$
46	Pin $\varnothing 2 \times 24$
47	Extend Charging Tube
48	Magazine Base Packing Support
49	Magazine Base Packing
50	Magazine Floor Plate
51	Magazine Charging Valve

